



HOUSEHOLD WATER QUALITY

Nitrates in Household Water

*Kathleen Parrott, Janice Woodard, and Blake Ross**

Nitrate (NO_3) is the primary source of nitrogen (N) for plants; they cannot live without this nutrient. Nitrate contamination of a water supply occurs when there is more nitrate in the soil than plants can use and when water can move easily through the soil and underlying rock. The excess nitrate is carried through the soil into groundwater supplies by irrigation water, rainwater, and snowmelt. This is most likely to occur when the soil is sandy or gravelly, and/or shallow water tables exist. Excess nitrate accumulate in the soil from several sources, including fertilizer, manure, and sewage.

Why are nitrates a problem?

High levels of nitrate in household water supplies can be of grave concern, especially to families with infants. Human babies are extremely susceptible to acute nitrate poisoning because of certain bacteria that may live in their digestive system during the first few months of life. These bacteria change nitrate into toxic nitrite (NO_2). The nitrite reacts with hemoglobin (which carries oxygen to all parts of the body) to form methemoglobin, which does not carry oxygen. The level of oxygen being carried throughout the body decreases in proportion to the amount of hemoglobin converted to methemoglobin. As the oxygen level decreases, the baby is gradually suffocated. This condition is called *methemoglobinemia*, commonly referred to as “blue baby” disease.

Around the age of three months, as the baby’s digestive system develops, stomach acid begins to kill most of the bacteria that convert nitrate to toxic nitrite. By the time a baby is about six months old, its digestive system is fully developed, and none of the nitrate-converting bacteria remain. In older children and adults, nitrate is absorbed and excreted, and methemoglobinemia is no longer a concern.

How much nitrate is dangerous?

Drinking water quality standards have been set by the Federal

government to offer the greatest protection to infants. The standard of 10 milligrams per liter (mg/l) nitrate-nitrogen ($\text{NO}_3\text{-N}$) or 45 milligrams nitrate (NO_3) has a small margin of safety built into it. Because of this safety factor, some adults can drink water exceeding the standard and show no adverse effects. However, high nitrate levels are usually an indication of surface water contamination of the water supply. Nitrate levels exceeding the standard are a warning of other water quality problems.

Because nitrate is tasteless and odorless, water must be chemically tested to determine if it is contaminated. If you are on a municipal or public water system, it is the responsibility of the water authority to test and treat the water supply to prevent nitrate contamination. If nitrate contamination occurs in a public water supply, customers may be warned not to feed the water to infants until the problem is corrected. However, if you are on a private or individual water system, it is your responsibility to monitor for nitrate.

How do you test for nitrates?

Water testing for nitrate needs to be done by an independent, certified laboratory. For more information about the location of these laboratories, contact the local Cooperative Extension office or county or city health department. Contact the laboratory for specific instructions required for collecting a water sample.

Nitrate levels in a well vary according to the time of year. For this reason, spring is the best time to test, since snowmelt and rains will leach any excess nitrate into the groundwater. Also, commercial fertilizer usage is generally greatest at this time of year.

When your report comes back from the lab after the water test, the nitrate concentrations can be reported either as nitrate (NO_3) or as nitrate-nitrogen ($\text{NO}_3\text{-N}$). Be sure to know which reporting system is being used since the acceptable

Portions of this publication are adapted with permission from Nitrate in Drinking Water by Karen H. Mancel, Ohio Cooperative Extension Service.

*Extension Specialist, Housing; Retired Extension Specialist, Home Management and Equipment; Extension Specialist, Biological Systems Engineering, respectively; Virginia Tech



VIRGINIA POLYTECHNIC INSTITUTE
AND STATE UNIVERSITY

Virginia Cooperative Extension programs and employment are open to all, regardless of race, color, religion, sex, age, veteran status, national origin, disability, or political affiliation. An equal opportunity/affirmative action employer. Issued in furtherance of Cooperative Extension work, Virginia Polytechnic Institute and State University, Virginia State University, and the U.S. Department of Agriculture cooperating. J. David Barrett, Director, Virginia Cooperative Extension, Virginia Tech, Blacksburg; Lorenza W. Lyons, Administrator, 1890 Extension Program, Virginia State, Petersburg.
VT/133/0302/2.5M/223005/356484



VIRGINIA STATE UNIVERSITY

concentrations of each are considerably different. If the lab reports its results as nitrate-nitrogen (NO₃-N), the drinking water quality standard is **10** milligrams per liter. The standard is **45** milligrams per liter if the results are reported as nitrate (NO₃). A milligram per liter (mg/l) is also equal to a part per million (ppm) in water analysis. If you are unsure of how to interpret the report, contact the lab, the local Extension office, or health department. It is important to check the lab report carefully because the two systems of reporting are frequently interchanged.

If your water supply has been tested and the report shows that the water has a high nitrate level, you must immediately stop feeding your water to infants. As alternatives to contaminated water, you can plan to breast feed, feed formula prepared with bottled distilled water, or feed pre-mixed infant formula. Pregnant and nursing mothers should not drink high nitrate water.

How do you prevent nitrate contamination?

Prevention of nitrate contamination of the water supply is critical. Wells need to be isolated from possible sources of contamination and to be protected from surface damage. Ensure the well itself is kept in good repair to prevent surface water from entering. Abandoned wells need to be sealed to prevent contamination. Sinkholes are direct routes to groundwater and should never be used as garbage dumps. Good nitrogen management is needed when storing and applying fertilizers, both on the farm and in the home yard and garden.

The surest way to deal with a contaminated water supply is to find a new, clean water supply. If you do not have access to a new water supply, the contaminated water can be treated to remove the nitrate.

How can nitrate be reduced or removed from water?

Nitrate is a very soluble substance, easily dissolved in water and extremely hard to remove. Treatment for nitrate is, therefore, very complicated and expensive. However, only water used for drinking and cooking needs to be treated. The methods of reducing or removing nitrate are: 1) demineralization by distillation or reverse osmosis; and 2) ion exchange.

Demineralization Demineralization removes nitrate and all other minerals from the water. Distillation is one of the most effective types of demineralization. The distilling process has three steps: 1) the water is boiled; 2) the resulting steam is caught; and 3) the steam is condensed on a cold surface, turning the water back into liquid form. The nitrate and other minerals remain concentrated in the boiling tank.

Reverse osmosis is another way to demineralize water. In a reverse osmosis system, the water is put under pressure and forced through a membrane that filters out minerals and nitrate.

Both of these demineralization systems require time and energy to operate efficiently. They are also low-yield systems, and storage space for treated water is required.

Ion Exchange The second type of water treatment for nitrate contamination is ion exchange, the same type of process used for water softening. Most often chloride is exchanged for nitrate. The ion-exchange unit is a tank filled with special resin beads that are charged with chloride. As water containing nitrate flows through the tank, the resin takes up the nitrate and replaces it with chloride. In time, all the chloride will be exchanged for nitrate. The resin can then be recharged by backwashing with a brine solution (sodium chloride) and reused.

Ion-exchange systems can treat large volumes of water. However, in addition to exchanging nitrate, the resin beads will also take up sulfate in exchange for chloride. Therefore, if sulfates are present in the water supply, the capacity of the resin to take up nitrate is reduced. Second, the exchange process may also make the water corrosive. For this reason, the water must go through a neutralizing system after going through the ion-exchange unit. Finally, the backwash brines, which are high in nitrate, must be disposed of properly so they do not recontaminate the groundwater supply.

There is no simple way to remove all nitrate from your water. Although it is common to think of boiling, softening, or filtration as a means of purifying water, none of these methods reduce nitrate contamination. Boiling water is, in fact, the worst thing to do because it actually concentrates the nitrate. Softening and filtration do nothing at all to remove nitrate.

For more information on water quality and treatment, contact your local Virginia Cooperative Extension office.

Remember that nitrate is an essential nutrient for plant growth. Only when there is too much nitrate in the soil does it become a problem in water. Routine water testing is important to protect the health of families. If nitrate levels in a water supply exceed the present water quality standards, low-nitrate water must be provided for infants to drink. Nitrogen management, the only long-term solution to nitrate contamination, requires consideration of all aspects of nitrogen use. The problem of nitrate contamination is not a simple one, but it must be faced to protect families, animals, and the environment.